

Ways to install a freestanding wine cellar

LIEBHERR

FREESTANDING



BUILT IN CAVITY (WITH CLEARANCE)



If building into cavity, please note the below requirements:

- Minimum air space above cabinet (mm): 50mm
- Minimum air space behind cabinet (mm): 50mm
- Minimum air space on sides of cabinet (mm): 15mm

BUILT IN CAVITY WITH VENTILATION (AIR SPACE OUT OF TOP OF BENCH)



If building into cavity with ventilation cut out, please note the below requirements:

- Ventilation opening/grille: Minimum 300cm² at top rear of cabinet.
- Minimum air space above cabinet (mm): 15mm
- Minimum air space behind cabinet (mm): 50mm
- Minimum air space on sides of cabinet (mm): 15mm

Whilst every effort is made to ensure all specifications and information in this flyer are correct at time of printing, Andi-Co Australia Pty. Ltd. reserve the right to make changes without notification. Where actual appliance measurements, specifications and ratings are crucial, we recommend that the actual appliance installation instructions that accompany each appliance be checked. Andi-Co Australia will not be liable for any loss.